

## ***SDM-USB-DIG Platform***

This user's guide describes the characteristics, operation, and use of the SDM-USB-DIG platform. It provides a detailed description of the hardware design. The SDM-USB-DIG platform is used as part of several Texas Instruments evaluation modules. This document supplements the documentation of the evaluation module kits.

### **Contents**

1	Related Documentation From Texas Instruments .....	2
2	SDM-USB-DIG Platform Overview .....	2
2.1	Hardware Included with the SDM-USB-DIG Platform .....	2
3	System Setup .....	3
4	Theory of Operation for SDM-USB-DIG Platform .....	3
4.1	Digital I/O Area .....	4
4.2	USB I/O .....	6
4.3	Power Indicators .....	6
4.4	Reset .....	7
4.5	DUT Power Switching .....	7
4.6	Main Connector Definition on SDM-USB-DIG .....	8
5	Schematic and Bill of Materials .....	9
5.1	SDM-USB-DIG Schematic .....	9
5.2	SDM-USB-DIG Bill of materials .....	10

### **List of Figures**

1	Included Hardware SDM-USB-DIG Platform .....	2
2	Typical Hardware Setup for the SDM-USB-DIG Platform .....	3
3	SDM-USB-DIG Platform Block Diagram .....	3
4	Digital I/O Area—Microcontroller.....	4
5	Digital I/O Area — I <sup>2</sup> C and SPI.....	5
6	Power Regulator .....	5
7	USB I/O.....	6
8	Power Indicators .....	6
9	Reset .....	7
10	DUT Power Switching .....	7
11	Main Connector (J3) .....	8
12	SDM-USB-DIG Schematic.....	9

### **List of Tables**

1	Related Documentation .....	2
2	Signal Definition of J3 (20-pin 50-mil Connector) on SDM-USB-DIG Platform .....	8
3	Bill of Materials .....	10

## 1 Related Documentation From Texas Instruments

The following related documents are available through the Texas Instruments web site at [www.ti.com](http://www.ti.com).

**Table 1. Related Documentation**

Device	Literature Number
MSP430F5528	<a href="#">SLAS590</a>
MSP430x5xx and MSP430x6xx Family User's Guide	<a href="#">SLAU208</a>
MSP430 Hardware Tools User's Guide	<a href="#">SLAU278</a>

Questions and any other comments regarding the platform can be sent to the Data Converters Forum on E2E. <http://e2e.ti.com/>

## 2 SDM-USB-DIG Platform Overview

The SDM-USB-DIG platform is a data acquisition system, which is used to create different communication protocols, and general-purpose I/O signals. Specifically, the system generates I<sup>2</sup>C, SPI, and general-purpose I/O signals. The system also generates a power-supply connection that has three options: +3.3 V, +5 V, and Hi-Z (0 V).

The purpose of the SDM-USB-DIG platform is for communication and I/O control of evaluation modules. An evaluation module is a printed-circuit board (PCB) that contains basic circuitry to test and evaluate a TI-specific device. In general, the SDM-USB-DIG connects to an evaluation module, along with the related cables and power supplies. An example of an EVM is the AMC7832EVM, which is a PCB with different circuitry developed around the AMC7832 TI device. This board connects to the SDM-USB-DIG platform and allows customers to test and evaluate the features of the AMC7832 device.

### 2.1 Hardware Included with the SDM-USB-DIG Platform

Figure 1 shows the hardware included with the SDM-USB-DIG platform.



**Figure 1. Included Hardware SDM-USB-DIG Platform**

### 3 System Setup

An example system setup for the SDM-USB-DIG is shown in [Figure 2](#). The PC runs software an executable GUI which communicates with the SDM-USB-DIG. The SDM-USB-DIG interprets the commands sent from the PC, and outputs different digital signals used to communicate with the EVM. EVMs typically contain hardware connections allowing users to access and connect external signals to the device under test (DUT). EVMs may also contain different jumper settings that enable different configurations for the DUT.




Figure 2. Typical Hardware Setup for the SDM-USB-DIG Platform

### 4 Theory of Operation for SDM-USB-DIG Platform

The SDM-USB-DIG platform is a general-purpose data acquisition system that is part of select TI EVMs. [Figure 3](#) illustrates a block diagram of the platform.

The core component of the platform is the MSP430F5528, an ultra-low power 16-bit MCU. The microcontroller receives information from the host PC and translates it into I<sup>2</sup>C, SPI, or other digital I/O patterns. The connected device, or DUT, connects to the I/O interface of the platform. During digital I/O transactions, the platform obtains information from the connected device and sends it to the host PC for interpretation.




Figure 3. SDM-USB-DIG Platform Block Diagram



### 4.1.2 I<sup>2</sup>C, SPI, and GPIO

Figure 5 displays the digital I/O area that manages I<sup>2</sup>C and SPI communications. U6 is an open collector bidirectional translator for SDA and SCL Lines. Note that the input level, 3.3 V, is translated to the programmed VDUT voltage: 3.3 V or 5 V. U4 and U3 are also bidirectional translators that level-shift the SPI signals and general purpose I/O lines to the programmed VDUT voltage.




Figure 5. Digital I/O Area — I<sup>2</sup>C and SPI

### 4.1.3 Power Regulator

The USB bus provides a +5-V input to an LDO voltage regulator, U1. U1 converts the +5-V input to a +3.3-V output. The +3.3-V output voltage is distributed to all blocks within the platform that require +3.3 V, Figure 6.





Figure 6. Power Regulator

## 4.2 USB I/O

The USB bus is accessed through the USB A – plug connection, J1. The plug connection connects the USB bus to the MSP430F5528 microcontroller, [Figure 7](#). The passive components are standard support circuitry for this device.




**Figure 7. USB I/O**

## 4.3 Power Indicators

The Power status of the platform can be visually verified through on board LEDs, D1 and D2. The LED D1, connected to the 3.3-V supply, powers on when the platform is connected to an active USB bus. The other LED, D2, activates when VDUT is programmed to 3.3 V or 5 V. [Figure 8](#) shows the LED power indicators.

**POWER INDICATORS**



**Figure 8. Power Indicators**

#### 4.4 Reset

The reset circuit consists of a power-on reset generator, U2, which resets the microcontroller upon power up. The device also supports manual reset through push button S1. Figure 9 displays the Reset output that connects to the microcontroller.




Figure 9. Reset

#### 4.5 DUT Power Switching

The SDM-USB-DIG platform incorporates a two-input, one-output power multiplexer, U8, which switches between 3.3 V and 5 V. The inputs to the multiplexer are used to select the VDUT voltage. More specifically, the power multiplexer is used to switch between the +5-V USB supply and the +3.3-V power regulator output. Software is used to programmatically set the VDUT output to +3.3 V, +5 V, or Hi-Z (disconnected). The DUT Power Switching module is illustrated in Figure 10.




Figure 10. DUT Power Switching

## 4.6 Main Connector Definition on SDM-USB-DIG

The SDM-USB-DIG contains one external connector, J3, which connects the platform to select TI EVMs. Figure 11 shows the "J3" connector.




Figure 11. Main Connector (J3)

### 4.6.1 Signal Definition of "J3" Main EVM Connector on SDM-USB-DIG Platform

Table 2 shows the different signals connected to J3 on the SDM-USB-DIG platform and gives a description of each signal.

Table 2. Signal Definition of J3 (20-pin 50-mil Connector) on SDM-USB-DIG Platform

PIN On J3	Signal	Description
1	SCL	I <sup>2</sup> C Clock Signal (SCL)
2	DIG_GPIO2	GPIO – Control Output or Measure Input
3	DIG_GPIO0	GPIO – Control Output or Measure Input
4	DIG_GPIO3	GPIO – Control Output or Measure Input
5	SDA	I <sup>2</sup> C Data Signal (SDA)
6	DIG_GPIO4	GPIO – Control Output or Measure Input
7	DIG_GPIO1	GPIO – Control Output or Measure Input
8	DIG_GPIO5	GPIO – Control Output or Measure Input
9	MOSI	SPI Data Output (MOSI)
10	DIG_GPIO6	GPIO – Control Output or Measure Input
11	VDUT	Switchable DUT Power Supply: +3.3 V, +5 V, Hi-Z (Disconnected). Note: When VDUT is Hi-Z all Digital I/O are Hi-Z as well.
12	DIG_GPIO7	GPIO – Control Output or Measure Input
13	SCLK	SPI Clock Signal (SCLK)
14	DIG_GPIO8	GPIO – Control Output or Measure Input
15	GND	Power Return (GND)
16	DIG_GPIO9	GPIO – Control Output or Measure Input
17	CS	SPI Chip Select Signal (/CS)
18	DIG_GPIO10	GPIO – Control Output or Measure Input
19	MISO	SPI Data Input (MISO)
20	DIG_GPIO11	GPIO – Control Output or Measure Input

## 5 Schematic and Bill of Materials

This section contains the SDM-USB-DIG schematic and BOM.

### 5.1 SDM-USB-DIG Schematic

The SDM-USB-DIG schematic is illustrated in [Figure 12](#).




Figure 12. SDM-USB-DIG Schematic

## 5.2 SDM-USB-DIG Bill of materials

Table 3 shows the parts list.

**Table 3. Bill of Materials**

Item	Qty	Ref Des	Description	MFR	Part Number
1	12	C1, C3, C12, C13, C14, C15, C16, C17, C18, C19, C21, C25	CAP CER 0.1UF 16V 10% X7R 0402	Murata	GRM155R71C104KA88D
2	1	C2	CAP CER 22UF 6.3V 20% X5R 0603	TDK	C1608X5R0J226M
3	2	C4, C22	CAP CER 10UF 6.3V 20% X5R 0603	Murata	GRM188R60J106ME47D
4	2	C5, C6	CAP CER 10000PF 50V 10% X7R 0402	Murata	GRM155R71H103KA88D
5	2	C7, C8	CAP CER 33PF 50V 5% NPO 0402	Murata	GCM1555C1H330JZ13D
6	3	C9, C20, C23	CAP CER 1UF 10V 10% X5R 0402	Murata	GRM155R61A105KE15D
7	2	C10, C11	CAP CER 22PF 50V 5% NPO 0402	Murata	GCM1555C1H220JZ13D
8	1	C24	CAP CER 0.47UF 10V 10% X5R 0402	Murata	GRM155R61A474KE15D
9	2	D1, D2	LED 565NM GRN DIFF 0603 SMD	Lumex	SML-LX0603GW-TR
10	1	F1	FERRITE 300mA 600 OHM 0603 SMD	Laird-Signal	HZ0603C601R-10
11	1	J1	CONN PLUG USB 4POS RT ANG SMD	Molex	480371000
12	0	J2	Not Installed		
13	1	J3	CONN HEADER RT ANG 2X50 .050	Mill-Max	852-10-100-20-001000
14	2	R1, R11	RES 33.0 OHM 1/10W 1% 0402 SMD	Panasonic	ERJ-2RKF33R0X
15	1	R2	RES 200K OHM 1/10W 1% 0402 SMD	Panasonic	ERJ-2RKF2003X
16	6	R3, R5, R13, R19, R20, R21	RES 100K OHM 1/10W 1% 0402 SMD	Panasonic	ERJ-2RKF1003X
17	1	R4	RES 1.40K OHM 1/10W 1% 0402 SMD	Panasonic	ERJ-2RKF1401X
18	2	R6, R7	RES 1.00M OHM 1/10W 1% 0402 SMD	Panasonic	ERJ-2RKF1004X
19	5	R8, R9, R14, R15, R18	RES 1.0K OHM 1/10W 5% 0402 SMD	Panasonic	ERJ-2GEJ102X
20	1	R10	RES 698 OHM 1/10W 1% 0402 SMD	Panasonic	ERJ-2RKF6980X
21	1	R12	RES 100 OHM 1/10W 1% 0402 SMD	Panasonic	ERJ-2RKF1000X
22	2	R16, R17	RES 510 OHM 1/10W 1% 0402 SMD	Panasonic	ERJ-2RKF5100X
23	2	S1, S2	SWITCH TACTILE SPST-NO 0.05A 12V	Omron	B3U-1000P
24	1	U1	IC REG LDO 3.3V .15A SOT-23-5	TI	TPS76333DBVR
25	1	U2	IC 2.64V NANOPWR MON SOT-23-5	TI	TPS3838L30DBVT
26	2	U3, U4	IC 8BIT NON-INV TRANSLTR 20TSSOP	TI	TXS0108EPWR
27	1	U5	IC MCU 16BIT 128KB FLASH 64VQFN	TI	MSP430F5528IRGCT
28	1	U6	IC VOLT LEVEL TRANSLATOR 8-VSSOP	TI	PCA9306DCUR
29	1	U7	IC POSITIVE-OR GATE 2-IN SC-70	TI	SN74LVC1G32DCKR
30	1	U8	IC AUTOSWITCH POWER MUX 8-TSSOP	TI	TPS2115ADRBR
31	1	X1	CRYSTAL 12.000 MHZ 18 PF SMD	Abracon	ABM8G-12.000MHZ-18-D2Y-T
32	1		Printed Circuit Board		6573758
33	1		Enclosure (blue)		TIENC-II

## EVALUATION BOARD/KIT/MODULE (EVM) ADDITIONAL TERMS

Texas Instruments (TI) provides the enclosed Evaluation Board/Kit/Module (EVM) under the following conditions:

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods.

Should this evaluation board/kit not meet the specifications indicated in the User's Guide, the board/kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING LIMITED WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

Please read the User's Guide and, specifically, the Warnings and Restrictions notice in the User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For additional information on TI's environmental and/or safety programs, please visit [www.ti.com/esh](http://www.ti.com/esh) or contact TI.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used. TI currently deals with a variety of customers for products, and therefore our arrangement with the user is not exclusive. TI assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein.

## REGULATORY COMPLIANCE INFORMATION

As noted in the EVM User's Guide and/or EVM itself, this EVM and/or accompanying hardware may or may not be subject to the Federal Communications Commission (FCC) and Industry Canada (IC) rules.

For EVMs **not** subject to the above rules, this evaluation board/kit/module is intended for use for ENGINEERING DEVELOPMENT, DEMONSTRATION OR EVALUATION PURPOSES ONLY and is not considered by TI to be a finished end product fit for general consumer use. It generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to part 15 of FCC or ICES-003 rules, which are designed to provide reasonable protection against radio frequency interference. Operation of the equipment may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures may be required to correct this interference.

### General Statement for EVMs including a radio

*User Power/Frequency Use Obligations:* This radio is intended for development/professional use only in legally allocated frequency and power limits. Any use of radio frequencies and/or power availability of this EVM and its development application(s) must comply with local laws governing radio spectrum allocation and power limits for this evaluation module. It is the user's sole responsibility to only operate this radio in legally acceptable frequency space and within legally mandated power limitations. Any exceptions to this are strictly prohibited and unauthorized by Texas Instruments unless user has obtained appropriate experimental/development licenses from local regulatory authorities, which is responsibility of user including its acceptable authorization.

### For EVMs annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant

#### Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### FCC Interference Statement for Class A EVM devices

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### **FCC Interference Statement for Class B EVM devices**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **For EVMs annotated as IC – INDUSTRY CANADA Compliant**

This Class A or B digital apparatus complies with Canadian ICES-003.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **Concerning EVMs including radio transmitters**

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

### **Concerning EVMs including detachable antennas**

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Cet appareil numérique de la classe A ou B est conforme à la norme NMB-003 du Canada.

Les changements ou les modifications pas expressément approuvés par la partie responsable de la conformité ont pu vider l'autorité de l'utilisateur pour actionner l'équipement.

### **Concernant les EVMs avec appareils radio**

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### **Concernant les EVMs avec antennes détachables**

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

## **【Important Notice for Users of EVMs for RF Products in Japan】**

**This development kit is NOT certified as Confirming to Technical Regulations of Radio Law of Japan**

If you use this product in Japan, you are required by Radio Law of Japan to follow the instructions below with respect to this product:

1. Use this product in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
2. Use this product only after you obtained the license of Test Radio Station as provided in Radio Law of Japan with respect to this product, or
3. Use of this product only after you obtained the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to this product. Also, please do not transfer this product, unless you give the same notice above to the transferee. Please note that if you could not follow the instructions above, you will be subject to penalties of Radio Law of Japan.

**Texas Instruments Japan Limited**  
**(address) 24-1, Nishi-Shinjuku 6 chome, Shinjuku-ku, Tokyo, Japan**

<http://www.tij.co.jp>

### **【無線電波を送信する製品の開発キットをお使いになる際の注意事項】**

本開発キットは技術基準適合証明を受けておりません。

本製品のご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
2. 実験局の免許を取得後ご使用いただく。
3. 技術基準適合証明を取得後ご使用いただく。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします。

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。

日本テキサス・インスツルメンツ株式会社

東京都新宿区西新宿 6 丁目 2 4 番 1 号

西新宿三井ビル

<http://www.tij.co.jp>

## **EVALUATION BOARD/KIT/MODULE (EVM) WARNINGS, RESTRICTIONS AND DISCLAIMERS**

**For Feasibility Evaluation Only, in Laboratory/Development Environments.** Unless otherwise indicated, this EVM is not a finished electrical equipment and not intended for consumer use. It is intended solely for use for preliminary feasibility evaluation in laboratory/development environments by technically qualified electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems and subsystems. It should not be used as all or part of a finished end product.

Your Sole Responsibility and Risk. You acknowledge, represent and agree that:

1. You have unique knowledge concerning Federal, State and local regulatory requirements (including but not limited to Food and Drug Administration regulations, if applicable) which relate to your products and which relate to your use (and/or that of your employees, affiliates, contractors or designees) of the EVM for evaluation, testing and other purposes.
2. You have full and exclusive responsibility to assure the safety and compliance of your products with all such laws and other applicable regulatory requirements, and also to assure the safety of any activities to be conducted by you and/or your employees, affiliates, contractors or designees, using the EVM. Further, you are responsible to assure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard.
3. Since the EVM is not a completed product, it may not meet all applicable regulatory and safety compliance standards (such as UL, CSA, VDE, CE, RoHS and WEEE) which may normally be associated with similar items. You assume full responsibility to determine and/or assure compliance with any such standards and related certifications as may be applicable. You will employ reasonable safeguards to ensure that your use of the EVM will not result in any property damage, injury or death, even if the EVM should fail to perform as described or expected.
4. You will take care of proper disposal and recycling of the EVM's electronic components and packing materials.

**Certain Instructions.** It is important to operate this EVM within TI's recommended specifications and environmental considerations per the user guidelines. Exceeding the specified EVM ratings (including but not limited to input and output voltage, current, power, and environmental ranges) may cause property damage, personal injury or death. If there are questions concerning these ratings please contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, some circuit components may have case temperatures greater than 60°C as long as the input and output are maintained at a normal ambient operating temperature. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors which can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during normal operation, please be aware that these devices may be very warm to the touch. As with all electronic evaluation tools, only qualified personnel knowledgeable in electronic measurement and diagnostics normally found in development environments should use these EVMs.

**Agreement to Defend, Indemnify and Hold Harmless.** You agree to defend, indemnify and hold TI, its licensors and their representatives harmless from and against any and all claims, damages, losses, expenses, costs and liabilities (collectively, "Claims") arising out of or in connection with any use of the EVM that is not in accordance with the terms of the agreement. This obligation shall apply whether Claims arise under law of tort or contract or any other legal theory, and even if the EVM fails to perform as described or expected.

**Safety-Critical or Life-Critical Applications.** If you intend to evaluate the components for possible use in safety critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, such as devices which are classified as FDA Class III or similar classification, then you must specifically notify TI of such intent and enter into a separate Assurance and Indemnity Agreement.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265  
Copyright © 2014, Texas Instruments Incorporated

## IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have **not** been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

### Products

Audio	<a href="http://www.ti.com/audio">www.ti.com/audio</a>
Amplifiers	<a href="http://amplifier.ti.com">amplifier.ti.com</a>
Data Converters	<a href="http://dataconverter.ti.com">dataconverter.ti.com</a>
DLP® Products	<a href="http://www.dlp.com">www.dlp.com</a>
DSP	<a href="http://dsp.ti.com">dsp.ti.com</a>
Clocks and Timers	<a href="http://www.ti.com/clocks">www.ti.com/clocks</a>
Interface	<a href="http://interface.ti.com">interface.ti.com</a>
Logic	<a href="http://logic.ti.com">logic.ti.com</a>
Power Mgmt	<a href="http://power.ti.com">power.ti.com</a>
Microcontrollers	<a href="http://microcontroller.ti.com">microcontroller.ti.com</a>
RFID	<a href="http://www.ti-rfid.com">www.ti-rfid.com</a>
OMAP Applications Processors	<a href="http://www.ti.com/omap">www.ti.com/omap</a>
Wireless Connectivity	<a href="http://www.ti.com/wirelessconnectivity">www.ti.com/wirelessconnectivity</a>

### Applications

Automotive and Transportation	<a href="http://www.ti.com/automotive">www.ti.com/automotive</a>
Communications and Telecom	<a href="http://www.ti.com/communications">www.ti.com/communications</a>
Computers and Peripherals	<a href="http://www.ti.com/computers">www.ti.com/computers</a>
Consumer Electronics	<a href="http://www.ti.com/consumer-apps">www.ti.com/consumer-apps</a>
Energy and Lighting	<a href="http://www.ti.com/energy">www.ti.com/energy</a>
Industrial	<a href="http://www.ti.com/industrial">www.ti.com/industrial</a>
Medical	<a href="http://www.ti.com/medical">www.ti.com/medical</a>
Security	<a href="http://www.ti.com/security">www.ti.com/security</a>
Space, Avionics and Defense	<a href="http://www.ti.com/space-avionics-defense">www.ti.com/space-avionics-defense</a>
Video and Imaging	<a href="http://www.ti.com/video">www.ti.com/video</a>

### TI E2E Community

[e2e.ti.com](http://e2e.ti.com)