




ALL ARTWORK VIEWED FROM TOP SIDE	BOARD #: PROC103	REV: C	SUN REV: Not In VersionControl
LAYER NAME = Top Solder	TID #: N/A		
PLOT NAME = Top Solder	GENERATED : 16-06-2022 19:53:56		TEXAS INSTRUMENTS







ALL ARTWORK VIEWED FROM TOP SIDE	BOARD #: PROC103	REV: C	SUN REV: Not In VersionControl
LAYER NAME = <small>MT Board Outline</small> Top Layer	TID #: N/A		
PLOT NAME = Top Layer	GENERATED : 16-06-2022 19:53:56	TEXAS INSTRUMENTS	




ALL ARTWORK VIEWED FROM TOP SIDE	BOARD #: PROC103	REV: C	SUN REV: Not In VersionControl
LAYER NAME = <small>MT Board Outline</small> GND1	TID #: N/A		
PLOT NAME = GND1	GENERATED : 16-06-2022 19:53:56	TEXAS INSTRUMENTS	




ALL ARTWORK VIEWED FROM TOP SIDE	BOARD #: PROC103	REV: C	SUN REV: Not In VersionControl
LAYER NAME = <small>MT Board Outline</small> SIG1	TID #: N/A		
PLOT NAME = SIG1	GENERATED : 16-06-2022 19:53:56	TEXAS INSTRUMENTS	




ALL ARTWORK VIEWED FROM TOP SIDE	BOARD #: PROC103	REV: C	SUN REV: Not In VersionControl
LAYER NAME = GND2 ^{MT Board Outline}	TID #: N/A		
PLOT NAME = GND2	GENERATED : 16-06-2022 19:53:56	TEXAS INSTRUMENTS	




ALL ARTWORK VIEWED FROM TOP SIDE	BOARD #: PROC103	REV: C	SUN REV: Not In VersionControl
LAYER NAME = <small>MT Board Outline</small> PWR1	TID #: N/A		
PLOT NAME = PWR1	GENERATED : 16-06-2022 19:53:57	TEXAS INSTRUMENTS	




ALL ARTWORK VIEWED FROM TOP SIDE	BOARD #: PROC103	REV: C	SUN REV: Not In VersionControl
LAYER NAME = <small>MT Board Outline</small> PWR2	TID #: N/A		
PLOT NAME = PWR2	GENERATED : 16-06-2022 19:53:57	TEXAS INSTRUMENTS	




ALL ARTWORK VIEWED FROM TOP SIDE	BOARD #: PROC103	REV: C	SUN REV: Not In VersionControl
LAYER NAME = <small>MT Board Outline</small> GND3	TID #: N/A		
PLOT NAME = GND3	GENERATED : 16-06-2022 19:53:57	TEXAS INSTRUMENTS	




ALL ARTWORK VIEWED FROM TOP SIDE	BOARD #: PROC103	REV: C	SUN REV: Not In VersionControl
LAYER NAME = <small>MS Board Outline</small> SIG2	TID #: N/A		
PLOT NAME = SIG2	GENERATED : 16-06-2022 19:53:57	TEXAS INSTRUMENTS	



ALL ARTWORK VIEWED FROM TOP SIDE	BOARD #: PROC103	REV: C	SUN REV: Not In VersionControl
LAYER NAME = GND4 ^{MT Board Outline}	TID #: N/A		
PLOT NAME = GND4	GENERATED : 16-06-2022 19:53:57	TEXAS INSTRUMENTS	



ALL ARTWORK VIEWED FROM TOP SIDE	BOARD #: PROC103	REV: C	SUN REV: Not In VersionControl
LAYER NAME = Bottom Layer	TID #:	N/A	
PLOT NAME = Bottom Layer	GENERATED	: 16-06-2022 19:53:57	TEXAS INSTRUMENTS



ALL ARTWORK VIEWED FROM TOP SIDE	BOARD #: PROC103	REV: C	SUN REV: Not In VersionControl
LAYER NAME = <small>MT Board Outline</small> Bottom Solder	TID #: N/A		
PLOT NAME = Bottom Solder	GENERATED : 16-06-2022 19:53:57		TEXAS INSTRUMENTS

